



Wiring Diagrams


AXIAL SA 220V-240V SINGLE PHASE




SA100, SA125, SA100A, SA125A, SA150




SA100C, SA125C, SA150C, SA100AC, SA125AC
SA150AC, SA150C, SA100TP1R, SA100HTPIR




SA100HCT, SA125HCT, SA100AHCT, SA125AHCT



SA100HCT, SA125HCT, SA100AHCT, SA125AHCT
(THESE MODELS CAN BE WIRED WITH REMOTE SWITCH,
ENSURE PULL CORD IS IN OFF POSITION AND REMOVE CORD)
SA100T, SA125T, SA100AT, SA125AT, SA150T



SA100CLV, SA100PIRLV



SA100LV, SA100ALV